

Sauce Station Installation Instructions (all models)

ITEMS REQUIRED:

4xM8 masonry bolts, 14mm Masonry bit and Drill, socket spanner, Level, a pencil, Card for template (optional), and appropriate safety wear



1. Hold the unit up to the wall, level the unit, and mark the position of the holes. (A card or paper hole template can also be used.)

When fixing to brick or similar use 4 x M8 Masonry Bolts (not supplied) drill the holes using a 14mm dia masonry drill.



2. Fit the masonry bolts (with sleeve) into the holes and remove the top two bolts (leaving the sleeves in place) Hook the bayonet holes of the case over the two lower bolts and loosely tighten. (these MUST be fully tightened shortly), this allows adjustments to be made when lining up the top bolts.



3. Re-fit the top two bolts and then **FULLY TIGHTEN ALL 4 BOLTS**, checking that the unit is level.



4. Lower the Napkin section (unfilled) into place ensuring the finger holes are uppermost. Slide in the mid-section sachets dispenser pressing it firmly down into place with the front lip on the **OUTSIDE** of the unit (as shown). Finally place the Sauce Lid on top, ensuring it locates into the slot at the back of the unit.

Finally the unit can be filled: Napkins from the front, and sachets from the front or by removing the top and filling the gravity feed compartments.

